



Enabling Legendary Discovery™

# LEGENDplex™

## Multi-Analyte Flow Assay Kit

**Cat. No. 741131**

**SARS-CoV-2 Serological IgG Panel (3-Plex) w/ FP**

**Cat. No. 741132**

**SARS-CoV-2 Serological IgG Panel (3-Plex) w/ VbP**

**Please read the entire manual before running the assay.**

[BioLegend.com](http://BioLegend.com)

***It is highly recommended that this manual be read in its entirety before using this product. Do not use this kit beyond the expiration date.***

*For Research Purposes Only. Not for use in diagnostic or therapeutic procedures. Purchase does not include or carry the right to resell or transfer this product either as a stand-alone product or as a component of another product. Any use of this product other than the permitted use without the express written authorization of BioLegend is strictly prohibited.*

<b>Table of Contents</b>	<b>Page</b>
<b>Chapter 1: KIT DESCRIPTION</b> .....	3
Introduction.....	3
Principle of the Assay.....	3
Beads Usage.....	4
Storage Information.....	5
Materials Supplied.....	6
Materials to be Provided by the End-User.....	6
Precautions.....	8
<b>Chapter 2: ASSAY PREPARATION</b> .....	9
Sample Collection and Handling.....	9
Reagent Preparation.....	9
Standard Preparation.....	9
Sample Dilution.....	10
<b>Chapter 3: ASSAY PROCEDURE</b> .....	11
Performing the Assay Using a Filter Plate.....	11
Performing the Assay Using a V- bottom Plate.....	14
<b>Chapter 4: FLOW CYTOMETER SETUP</b> .....	17
<b>Chapter 5: DATA ACQUISITION AND ANALYSIS</b> .....	17
Data Acquisition.....	17
Data Analysis.....	18
<b>Chapter 6: ASSAY CHARACTERIZATION</b> .....	19
Representative Standard Curve.....	19
Assay Sensitivity.....	19
Cross-Reactivity.....	20
Accuracy.....	20
Linearity of Dilution.....	20

LEGENDplex™ SARS-CoV-2 Serological IgG Panel

Intra-Assay Precision..... 21  
Inter-Assay Precision..... 21  
Biological Samples..... 22

**TROUBLESHOOTING..... 24**

**PLATE MAP..... 29**

## Chapter 1: KIT DESCRIPTION

### Introduction

Severe Acute Respiratory Syndrome Coronavirus 2 (SARS-CoV-2) is a single stranded RNA virus that belongs to a family of viruses known as coronaviruses. SARS-CoV-2 infection, known as COVID-19, was declared a pandemic in 2020, and among other symptoms, leads to respiratory infection and pulmonary failure which can be fatal. SARS-CoV-2 is structurally composed of 4 main proteins (spike glycoprotein, envelope glycoprotein, membrane glycoprotein and nucleocapsid protein) and several accessory proteins. The coronavirus spike (S) glycoprotein contains a receptor binding domain (RBD) and is a viral fusion protein on the outer envelope of the virion that plays a critical role in viral infection by mediating fusion of the viral and cellular membranes. Nucleocapsid (N) is another abundant protein that binds to the viral RNA and helps stabilize it. The N protein is a major antigen that elicits host immune response following SARS CoV-2 infection, making it a promising candidate for vaccine development and drug therapy. IgG, IgA and IgM are three types of immunoglobulins that are targeted in COVID-19 serological testing. IgA and IgM are produced during early stages of virus infection. The IgA response declines quickly during infection, while the IgM response dissipates at a slower rate. The IgG response develops gradually and its levels are sustained after infection. Studying the expression profiles of immunoglobulins against these viral targets during and after infection is critical to understanding the physiological response against COVID-19.

The LEGENDplex™ SARS-CoV-2 Serological IgG Panel is a bead-based multiplex assay, utilizing fluorescence–encoded beads suitable for use on various flow cytometers. This panel allows simultaneous quantification of 3 human antibodies, including IgG antibodies against SARS-CoV-2 Spike Protein S1, Nucleocapsid, and Spike Protein RBD. This panel provides high sensitivities and a broad dynamic range. The panel has been validated for use on serum and plasma samples. The SARS-CoV-2 Serological IgG Panel is designed to allow flexible customization. For mix and match within the panel, please visit [www.biologend.com/legendplex](http://www.biologend.com/legendplex).

This assay is for research use only

### Principle of the Assay

BioLegend's LEGENDplex™ assays are bead-based immunoassays that use the same basic principle as sandwich immunoassays.

Beads are differentiated by size and internal fluorescence intensities. The surface of each bead set is first conjugated with specific proteins, and then used as capture beads for that particular analyte. When a selected panel of capture beads are mixed and incubated with a sample containing target analytes, each analyte will bind to its specific capture beads. After washing, a biotinylated

# LEGENDplex™ SARS-CoV-2 Serological IgG Panel

detection antibody is added, and the detection antibody will bind to its specific analyte bound on the capture beads, thus forming capture bead-analyte-detection antibody sandwiches. Streptavidin-phycoerythrin (SA-PE) is subsequently added, which will bind to the biotinylated detection antibody, providing fluorescent signal intensities in proportion to the amount of bound analytes.


Since the beads are differentiated by size and internal fluorescence intensity on a flow cytometer, analyte-specific populations can be segregated and PE fluorescent signal quantified. The concentration of a particular analyte is determined using a standard curve generated in the same assay.

## Beads Usage

The LEGENDplex™ beads-based assay usually includes two sets of beads. Each set has a unique size that can be identified based on their forward scatter (FSC) and side scatter (SSC) profiles (Beads A and Beads B, Figure 1). Each bead set can be further resolved based on their internal fluorescence intensities. The internal dye can be detected using either the FL3, FL4, or APC channels, depending on the type of flow cytometer used. The smaller A Beads consists of 6 bead populations (A4, A5, A6, A7, A8, A10) and the larger B Beads consists of 7 bead populations (B2, B3, B4, B5, B6, B7, B9) (Figure 2-3).

The SARS-CoV-2 Serological IgG Panel uses only 3 of the 13 bead populations (B2, B4, B5) distinguished by size and internal fluorescent dye.

**Figure 1. Beads Differentiated by Size**



Beads A = smaller beads

Beads B = larger beads

**Figure 2. Beads A Classification by FL4**





Figure 3. Beads B Classification by FL4



For Beads usage in the full panel, please refer to Table 1 below.

Table 1. Panel Targets and Bead ID\*

Target	Bead ID	Top Standard Concentrations
Anti-Spike S1 IgG	B2	The top standard concentrations may vary and may be subject to change from lot to lot. Please refer to the lot-specific Certificate of Analysis (CoA) for this information.
Anti-Nucleocapsid IgG	B4	
Anti-S Protein RBD IgG	B5	

\*Bead ID is used to associate a bead population to a particular analyte when using the LEGENDplex™ data analysis software program. For further information regarding the use of the program please visit [biolegend.com/en-us/legendplex](https://www.biolegend.com/en-us/legendplex)

### Storage Information

Recommended storage for all original kit components is between 2°C and 8°C. DO NOT FREEZE Pre-mixed Beads, Detection Antibodies or SA-PE.

- Once the standards have been sufficiently reconstituted, immediately transfer contents into polypropylene vials. DO NOT STORE RECONSTITUTED STANDARDS IN GLASS VIALS.
- Upon reconstitution, leftover top standard should be stored at  $\leq -70^{\circ}\text{C}$  for use within one month. Avoid multiple (>2) freeze-thaw cycles. Discard any leftover diluted standards.

# LEGENDplex™ SARS-CoV-2 Serological IgG Panel

## Materials Supplied

The LEGENDplex™ kit contains reagents for 100 tests, listed in the table below. When assayed in duplicate, this is enough for an 8-point standard curve and 40 samples.

Kit Components	Quantity	Volume	Part #
Setup Beads 1: FITC Beads	1 vial	1 mL	77840
Setup Beads 2: PE Beads	1 vial	1 mL	77842
Setup Beads 3: Raw Beads	1 vial	2 mL	77844
SARS-CoV-2 Serological IgG Panel Pre-mixed Beads	1 bottle	3.5 mL	750002280
SARS-CoV-2 Serological Panel IgG Det. Ab	1 bottle	3.5 mL	750002277
SARS-CoV-2 Serological Panel Standard	1 vial	Lyophilized	750002279
LEGENDplex™ SA-PE	1 bottle	3.5 mL	77743
LEGENDplex™ Assay Buffer	2 bottles	25 mL	77562
LEGENDplex™ Wash Buffer, 20X	1 bottle	25 mL	77564
Filter Plate* or V-bottom Plate**	1 plate	--	76187* or 76883**
Plate Sealers	4 sheets	--	78101

\* For kit with filter plate. \*\* For kit with V-bottom plate. Only one plate is provided for each kit.

## Materials to be Provided by the End-User

- A flow cytometer equipped with two lasers (e.g., a 488 nm blue laser or 532 nm green laser and a 633-635 nm red laser) capable of distinguishing 575 nm and 660 nm or a flow cytometer equipped with one laser (e.g., 488 nm blue laser) capable of distinguishing 575 nm and 670 nm.

### **Partial list of compatible flow cytometers:**

Flow Cytometer	Reporter Channel	Reporter Emission	Classification Channel	Channel Emission	Compensation needed?
BD FACSCalibur™	FL2	575 nm	FL4	660 nm	No*
BD Accuri™ C6	FL2	585 nm	FL4	675 nm	No*
BD FACSCanto™, BD FACSCanto™ II	PE	575 nm	APC	660 nm	No*

## LEGENDplex™ SARS-CoV-2 Serological IgG Panel

BD™ LSR, LSR II BD LSRFortessa™	PE	575 nm	APC	660 nm	No*
Gallios™	PE	575 nm	APC	660 nm	No*
CytoFLEX	PE	585 nm	APC	660 nm	No*
NovoCyte	PE	572 nm	APC	660 nm	No*
Attune™ NxT	PE	574 nm	APC	670 nm	No*
Guava® easyCyte	YLW	583 nm	RED2	661 nm	No*
Sony SH800	PE	585 nm	APC	665 nm	No*

**\*Compensation is not required for the specified flow cytometers when set up properly.**

For setting up various flow cytometers, please visit: [www.biolegend.com/legendplex](http://www.biolegend.com/legendplex) and click on the **Instrument Setup** tab.

- Multichannel pipettes capable of dispensing 5 µL to 200 µL
- Reagent reservoirs for multichannel pipette
- Polypropylene microfuge tubes (1.5 mL)
- Micro FACS tubes, 1.1 mL (if the flow cytometer does not contain an autosampler)
- Laboratory vortex mixer
- Sonicator bath (e.g., Branson Ultrasonic Cleaner model #B200, or equivalent)
- Aluminum foil
- Absorbent pads or paper towels
- Plate shaker (e.g., Lab-Line Instruments model #4625, or equivalent)
- Tabletop centrifuges (e.g., Eppendorf centrifuge 5415 C, or equivalent)
- 1.1 mL Mini FACS tubes

### **If the assay is performed in a filter plate:**

- A vacuum filtration unit (Millipore MultiScreen® HTS Vacuum Manifold, cat # MSVMHTS00 or equivalent). Instructions on how to use the vacuum manifold can be found at the supplier's website.
- A vacuum source (mini vacuum pump or line vacuum, e.g., Millipore Vacuum Pump, catalog # WP6111560, or equivalent)
- If needed, additional Filter plates can be ordered from BioLegend (Cat# 740377 or 740378).

### **If the assay is performed in a V-bottom plate:**

- Centrifuge with a swinging bucket adaptor for microtiter plates (e.g., Beckman Coulter Allegra™ 6R Centrifuge with MICROPLUS CARRIER adaptor for

# LEGENDplex™ SARS-CoV-2 Serological IgG Panel

GH3.8 and JS4.3 Rotors) .

- If needed, additional V-bottom plates can be ordered from BioLegend (Cat# 740379).

## **Precautions**

- All blood components and biological materials should be handled as potentially hazardous. Follow universal precautions as established by the Center for Disease Control and Prevention and by the Occupational Safety and Health Administration when handling and disposing of infectious agents.
- Sodium azide has been added to some reagents as a preservative. Although the concentrations are low, sodium azide may react with lead and copper plumbing to form highly explosive metal azides. On disposal, flush with a large volume of water to prevent azide build-up.
- Do not mix or substitute reagents from different kits or lots. Reagents from different manufacturers should not be used with this kit.
- Do not use this kit beyond its expiration date.
- SA-PE and beads are light-sensitive. Minimize light exposure.

## Chapter 2: ASSAY PREPARATION

### Sample Collection and Handling

#### Preparation of Serum Samples:

- Allow the blood to clot for at least 30 minutes and centrifuge for 20 minutes at 1,000 x *g*.
- Remove serum and assay immediately or aliquot and store samples at ≤-20°C. Avoid multiple (>2) freeze/thaw cycles.
- When using frozen samples, it is recommended that samples be thawed completely, mixed and centrifuged to remove particulates prior to use.

#### Preparation of Plasma Samples:

- Plasma collection should be collected using an anti-coagulant (e.g., EDTA, Citrate, Heparin). Centrifuge for 20 minutes at 1,000 x *g* within 30 minutes of blood collection.
- Remove plasma and assay immediately, or aliquot and store samples at ≤-20°C. Avoid multiple (>2) freeze/thaw cycles.
- When using frozen samples, it is recommended that samples be thawed completely, mixed well and centrifuged to remove particulates.

### Reagent Preparation

#### Preparation of Protein-Immobilized Beads

Sonicate pre-mixed Beads bottle for 1 minute in a sonicator bath and then vortex for 30 seconds prior to use. If no sonicator bath is available, increase the vortexing time to 1 minute to completely resuspend the beads.

#### Preparation of Wash Buffer

- Bring the 20X Wash Buffer to room temperature and mix to bring all salts into solution.
- Dilute 25 mL of 20X Wash Buffer with 475 mL deionized water. Store unused portions between 2°C and 8°C for up to one month.

### Standard Preparation

1. Prior to use, reconstitute the lyophilized SARS-CoV-2 Serological Panel Standard with 250 µL LEGENDplex™ Assay Buffer.

## LEGENDplex™ SARS-CoV-2 Serological IgG Panel

- Mix and allow the vial to sit at room temperature for 15 minutes, and then transfer the standard to an appropriately labeled polypropylene microcentrifuge tube. This will be used as the top standard C7.

**Note: The top standard concentrations of analytes in this panel were set at various concentrations, but may be subject to change from lot to lot (please visit [biolegend.com/en-us/legendplex](https://www.biolegend.com/en-us/legendplex) to download a lot-specific certificate of analysis).**

- Label 6 polypropylene microcentrifuge tubes as C6, C5, C4, C3, C2 and C1, respectively.
- Add 75  $\mu\text{L}$  of Assay Buffer to each of the six tubes. Prepare 1:4 dilution of the top standard by transferring 25  $\mu\text{L}$  of the top standard C7 to the C6 tube and mix well. This will be the C6 standard.
- In the same manner, perform serial 1:4 dilutions to obtain C5, C4, C3, C2 and C1 standards (see the table below using the top standard at 10,000  $\text{pg/mL}$  as an example). Assay Buffer will be used as the 0  $\text{pg/mL}$  standard (C0).

Tube/Standard ID	Serial Dilution	Assay Buffer to add ( $\mu\text{L}$ )	Standard to add	Final Conc. ( $\text{pg/mL}$ )
C7	--	--	--	10,000
C6	1:4	75	25 $\mu\text{L}$ of C7	2,500
C5	1:16	75	25 $\mu\text{L}$ of C6	625
C4	1:64	75	25 $\mu\text{L}$ of C5	156.25
C3	1:256	75	25 $\mu\text{L}$ of C4	39.01
C2	1:1024	75	25 $\mu\text{L}$ of C3	9.77
C1	1:4096	75	25 $\mu\text{L}$ of C2	2.44
C0	--	75	--	0

### Sample Dilution

- Serum or plasma samples must be diluted 800-fold with LEGENDplex™ Assay Buffer before being tested (e.g. dilute 1  $\mu\text{L}$  of sample with 99  $\mu\text{L}$  of LEGENDplex™ Assay Buffer and further serially dilute 20  $\mu\text{L}$  of that mixture into 140  $\mu\text{L}$  of LEGENDplex™ Assay Buffer).
- Adding serum or plasma samples without dilution will result in low assay accuracy and possibly, clogging of the filter plate.**

## Chapter 3: ASSAY PROCEDURE

The LEGENDplex™ assay can be performed in a filter plate, or in a V-bottom plate.

### Performing the Assay Using a Filter Plate

- Allow all reagents to warm to room temperature (20-25°C) before use.
  - Set the filter plate on an inverted plate cover at all times during assay setup and incubation steps, so that the bottom of the plate does not touch any surface. Touching a surface may cause leakage.
  - Keep the plate upright during the entire assay procedure, including the washing steps, to avoid losing beads.
  - The plate should be placed in the dark or wrapped with aluminum foil for all incubation steps.
  - **Standards and samples should be run in duplicate and arranged on the plate in a vertical configuration convenient for data acquisition and analysis (as shown in attached PLATE MAP, page 29). Be sure to load standards in the first two columns. If an automation device is used for reading, the orientation and reading sequence should be carefully planned.**
1. Pre-wet the plate by adding 100 µL of LEGENDplex™ 1X Wash Buffer to each well and let it sit for 1 minute at room temperature. To remove the excess volume, place the plate on the vacuum manifold and apply vacuum. Do not exceed 10" Hg of vacuum. Vacuum until wells are drained (5-10 seconds). Blot excess Wash Buffer from the bottom of the plate by pressing the plate on a stack of clean paper towels. Place the plate on top of the inverted plate cover.
  2. Load the plate as shown in the table below (in the order from left to right)

#### **For measuring serum or plasma samples:**

	Assay Buffer	Standard	Sample*
Standard Wells	25 µL	25 µL	---
Sample wells	25 µL	---	25 µL

\*See **Sample Dilution on page 10**

3. Vortex mixed beads bottle for 30 seconds. Add 25 µL of mixed beads to each well. The volume should be 75 µL in each well after beads addition. (Note: During addition of the beads, shake mixed beads bottle intermittently to avoid bead settling).
4. Seal the plate with a plate sealer. **To avoid plate leaking, do not apply posi-**

## LEGENDplex™ SARS-CoV-2 Serological IgG Panel

**tive pressure to the sealer when sealing the plate.** Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker, secure it with a rubber band and shake at approximate 500 rpm for 2 hours at room temperature.

5. **Do not invert the plate!** Place the plate on the vacuum manifold and apply vacuum as before in Step 1. Add 200  $\mu\text{L}$  of 1X Wash Buffer to each well. Remove Wash Buffer by vacuum filtration. Blot excess Wash Buffer from the bottom of the plate with an absorbent pad or paper towels. Repeat this washing step once more.
6. Add 25  $\mu\text{L}$  of Detection Antibodies to each well.
7. Seal the plate with a fresh plate sealer. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker and shake at approximately 500 rpm for 1 hour at room temperature.
8. **Do not vacuum!** Add 25  $\mu\text{L}$  of SA-PE to each well directly.
9. Seal the plate with a fresh plate sealer. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker and shake at approximate 500 rpm for 30 minutes at room temperature.
10. Repeat step 5 above.
11. Add 150  $\mu\text{L}$  of 1X Wash Buffer to each well. Resuspend the beads on a plate shaker for 1 minute.
12. Read samples on a flow cytometer, preferably within the same day of the assay (Note: Prolonged sample storage can lead to reduced signal).

If the flow cytometer is equipped with an autosampler, read the plate directly using the autosampler. **Please be sure to program the autosampler to resuspend beads in the well immediately before taking samples. The probe height may need to be adjusted when using an autosampler.**


If an autosampler is not available, the samples can be transferred from the filter plate to micro FACS (or FACS) tubes and read manually.

# LEGENDplex™ SARS-CoV-2 Serological IgG Panel

## Assay Procedure Summary for Filter Plate


Add 100  $\mu$ L 1X Wash Buffer to filter plate wells

Vacuum to remove excess buffer



Add to the plate:  
25  $\mu$ L Assay Buffer to all wells  
25  $\mu$ L diluted standard to standard wells  
or 25  $\mu$ L sample to sample wells  
25  $\mu$ L pre-mixed beads to all wells


Incubate 2 hours, RT, shaking



Wash 2 times using vacuum filtration unit

Add 25  $\mu$ L Detection Antibodies

Incubate 1 hr, RT, shaking



 Biotinylated Detection Antibody

Without washing, add 25  $\mu$ L SA-PE

Incubate 30 min, RT, shaking

Wash 2 times using vacuum filtration unit

Add 150  $\mu$ L of 1x Wash Buffer

Read on a flow cytometer

**Performing the Assay Using a V-bottom Plate**

- Allow all reagents to warm to room temperature (20-25°C) before use.
- Keep the plate upright during the entire assay procedure, except during the washing steps, to avoid losing beads.
- The plate should be placed in the dark or wrapped with aluminum foil for all incubation steps.
- Standards and samples should be run in duplicate and arranged on the plate in a vertical configuration convenient for data acquisition and analysis (as shown in attached PLATE MAP, page 29). Be sure to load standards in the first two columns. If an automation device is used for reading, the orientation and reading sequence should be carefully planned.

1. load the plate as shown in the table below (in the order from left to right)

**For measuring serum or plasma samples:**

	Assay Buffer	Standard	Sample*
Standard Wells	25 µL	25 µL	---
Sample wells	25 µL	---	25 µL

\*See **Sample Dilution on page 10**

2. Vortex mixed beads for 30 seconds. Add 25 µL of mixed beads to each well. The total volume should be 75 µL in each well after beads addition. (Note: During beads addition, shake mixed beads bottle intermittently to avoid bead settling).
3. Seal the plate with a plate sealer. Cover the entire plate with aluminum foil to protect the plate from light. Shake at 800 rpm on a plate shaker for 2 hours at room temperature (**Depending on the shaker, the speed may need to be adjusted. The optimal speed is one that is high enough to keep beads in suspension during incubation, but not too high that it may cause sample to spill from the wells.**)
4. Centrifuge the plate at 1050 rpm (~250 g) for 5 minutes, using a swinging bucket rotor (G.H 3.8) with microplate adaptor (Please refer to **Materials to be Provided by the End-User, page 6**). Do not use excessive centrifugation speed as it may make it harder to resuspend beads in later steps. **Make sure the timer of the centrifuge works properly and standby to make sure the centrifuge reaches preset speed.**
5. Immediately after centrifugation, dump the supernatant into a biohazard waste container by quickly inverting and flicking the plate **in one continuous and forceful motion**. The beads pellet may or may not be visible after dumping the supernatant. Blot the plate on a stack of clean paper towel and drain the remaining liquid from the well as much as possible. Be careful not to disturb the bead pellet.

## LEGENDplex™ SARS-CoV-2 Serological IgG Panel

Alternatively, removal of the supernatant may be completed using a multichannel pipette set at 75  $\mu$ L. Try to remove as much liquid as possible without removing any beads. Be sure to change pipette tips between each row or column.


6. Wash the plate by dispensing 200  $\mu$ L of 1X Wash Buffer into each well and incubate for one minute. Repeat step 4 and 5 above. A second wash is optional, but may help reduce background.
7. Add 25  $\mu$ L of Detection Antibodies to each well.
8. Seal the plate with a new plate sealer. Cover the entire plate with aluminum foil to protect the plate from light. Shake at 800 rpm on a plate shaker for 1 hour at room temperature.
9. **Do not wash the plate!** Add 25  $\mu$ L of SA-PE to each well directly.
10. Seal the plate with a new plate sealer. Wrap the entire plate with aluminum foil and shake the plate on a plate shaker at approximate 800 rpm for 30 minutes at room temperature.
11. Repeat step 4, and 5.
12. (This washing step is optional but helps to reduce the background.) Wash the plate by dispensing 200  $\mu$ L of 1X Wash Buffer into each well and incubate for one minute. Repeat step 4 and 5 above.
13. Add 150  $\mu$ L of 1X Wash Buffer to each well. Resuspend the beads by pipetting.
14. Read samples on a flow cytometer, preferably within the same day of the assay (Note: Prolonged sample storage can lead to reduced signal).

If the flow cytometer is equipped with an autosampler, the samples can be read directly. **Please be sure to program the autosampler to resuspend beads in the well immediately before taking samples. The probe height may need to be adjusted when using an autosampler.**

If an autosampler is not available, the samples can be transferred from the plate to micro FACS (or FACS) tubes and read manually.

# LEGENDplex™ SARS-CoV-2 Serological IgG Panel

## Assay Procedure Summary for V-bottom Plate



## Chapter 4: FLOW CYTOMETER SETUP

In order to generate reliable data, the flow cytometer must be set up properly before data acquisition.

The setup instructions have been removed from this manual and uploaded onto our website to save paper.

To access the setup instructions, please visit: [www.biolegend.com/legendplex](http://www.biolegend.com/legendplex) and click on the **Instrument Setup** tab.

## Chapter 5: DATA ACQUISITION AND ANALYSIS

### Data Acquisition

1. Before reading samples, make sure that the flow cytometer is set up properly.
2. Create a new template or open an existing template (for details on how to create a cytometer-specific template, please refer to the Flow Cytometer Setup Guide).
3. Vortex each sample for 5 seconds before analysis.
4. Set the flow rate to low. Set the number of beads to be acquired to about 300 per analyte (e.g., acquire 2,400 beads for a 8-plex assay or 3,000 beads for a 13-plex assay). Do not set to acquire total events as samples may contain large amounts of debris. Instead, create a large gate to include both Beads A and Beads B (gate A+B) and set to acquire the number of events in gate A + B. This will exclude majority of the debris.

Note: Do not acquire too few or too many beads. Too few beads acquired may result in high CVs and too many beads acquired may result in slow data analysis later.

5. Read samples.

When reading samples, set the flow cytometer to setup mode first and wait until bead population is stabilized before recording or switching to acquisition mode.

To simplify data analysis using the LEGENDplex™ Data Analysis Software, read samples in the same order as shown on the PLATE MAP attached at the end of the manual. For an in-plate assay, read column by column (A1, B1, C1...A2, B2, C2...).

## LEGENDplex™ SARS-CoV-2 Serological IgG Panel

When naming data files, try to use simple names with a consecutive numbering for easy data analysis (e.g. for standards, C0.001, C0.002, C1.003, C1.004, C2.005, C2.006, C3.007, C3.008, ... C7.015, C7.016; for samples, S1.017, S1.018, S2.019, S2.020, S3.021, S3.022...)

Store all FCS files in the same folder for each assay. If running multiple assays, create a separate folder for each assay.

6. Proceed to data analysis using LEGENDplex™ Data Analysis Software when data acquisition is completed.


### Data Analysis

- The assay FCS files should be analyzed using BioLegend's LEGENDplex™ data analysis software. The program is offered free of charge with the purchase of any LEGENDplex™ assay. For further information regarding access to, and use of the program please visit [biolegend.com/en-us/legendplex](https://www.biolegend.com/en-us/legendplex).
- Concentrations reported below C2 of the standard curve should be considered inconclusive.

## Chapter 6: ASSAY CHARACTERIZATION

### Representative Standard Curve

This standard curve was generated using the LEGENDplex™ SARS-CoV-2 Serological IgG Panel for demonstration purposes only. A standard curve must be run with each assay.



### Assay Sensitivity

The assay sensitivity or minimum detectable concentration (MDC) is the theoretical limit of detection calculated using the LEGENDplex™ Data Analysis Software by applying a 5-parameter curve fitting algorithm. The formula for assay sensitivity presented below is (MDC + 2STDEV).

Analyte	Sensitivity (ng/mL) (N = 9)
Anti-Spike S1 IgG	0.046+0.026
Anti-Nucleocapsid IgG	0.060+0.047
Anti-S Protein RBD IgG	0.050+0.020

# LEGENDplex™ SARS-CoV-2 Serological IgG Panel

## Cross-Reactivity

Target antibodies were tested individually at the indicated concentrations below using the LEGENDplex™ SARS-CoV-2 Serological IgG Panel, with negligible cross-reactivity observed for non-intended targets.

Analyte	Conc. (ng/mL)
Anti-Spike S1 IgG	5,000
Anti-Nucleocapsid IgG	5,000
Anti-S Protein RBD IgG	5,000

## Accuracy (Spike Recovery)

For spike recovery in serum and plasma, samples were spiked with target recombinant antibodies at three different levels within the assay range. The spiked samples were then assayed, and the measured concentrations were compared with the expected values.

Analyte	% of Recovery in Serum (N=8)	% of Recovery in Plasma (N=24)
Anti-Spike S1 IgG	104%	101%
Anti-Nucleocapsid IgG	95%	106%
Anti-S Protein RBD IgG	101%	96%

## Linearity of Dilution

Serum and plasma samples were initially diluted 400-fold with Assay Buffer, spiked with target recombinant antibody, then serially diluted 2, 4, 8 fold in Assay Buffer and assayed.

The measured concentrations of serially diluted samples were then compared with the concentration of the lowest dilution based on serial dilution factor used.

Analyte	% Linearity	
	Serum (N=8)	Plasma (N=24)
Anti-Spike S1 IgG	93%	93%
Anti-Nucleocapsid IgG	93%	95%
Anti-S Protein RBD IgG	92%	91%

**Intra-Assay Precision**

Two samples with different concentrations of each target antibody were analyzed in one assay with 16 replicates per sample. The intra-assay precision is shown below.

Analyte	Sample	Mean (ng/mL)	STDEV	%CV
Anti-Spike S1 IgG	Sample 1	28.95	0.71	2%
	Sample 2	7.63	0.12	2%
Anti-Nucleocapsid IgG	Sample 1	29.82	0.99	3%
	Sample 2	7.72	0.25	3%
Anti-S Protein RBD IgG	Sample 1	29.35	0.75	3%
	Sample 2	7.35	0.13	2%

**Inter-Assay Precision**

Two samples with different concentrations of each target antibody were analyzed in ten independent assays with four replicates per sample. The inter-assay precision is shown below.

Analyte	Sample	Mean (pg/mL)	STDEV	%CV
Anti-Spike S1 IgG	Sample 1	26.42	2.16	8%
	Sample 2	6.64	0.92	14%
Anti-Nucleocapsid IgG	Sample 1	26.35	2.41	9%
	Sample 2	6.60	0.96	15%
Anti-S Protein RBD IgG	Sample 1	26.48	3.30	12%
	Sample 2	6.32	0.96	15%

# LEGENDplex™ SARS-CoV-2 Serological IgG Panel

## Biological Samples

The values in this section are provided for reference only. The assays provided in this kit are intended for research use only.

### Serum

Serum samples from matched sets collected from 20 healthy human donors prior to the COVID-19 pandemic were tested for endogenous levels of the target antibodies. Pre-existing SARS-CoV-2 reactive antibodies have been reported at low levels in healthy donor cohorts<sup>1</sup>, inconclusive data may reflect this phenomenon and can be verified with clinical information. Concentrations reported between the minimum detectable concentration and C2 (0.488 ng/mL) were considered inconclusive and excluded from calculating % of detectable. Users may modify this cutoff. The concentrations after multiplying by the dilution factor are shown below (in ng/mL).

Analyte	Range (ng/mL)	% Detectable	Median (ng/mL)
Anti-Spike S1 IgG	ND-176	0%	0
Anti-Nucleocapsid IgG	ND-4480	5%	80
Anti-S Protein RBD IgG	ND-64	0%	0

### Plasma

Heparin, EDTA, and Citrate plasma samples from matched sets collected from 20 healthy human donors prior to the COVID-19 pandemic were tested for endogenous levels of the target antibodies. Pre-existing SARS-CoV-2 reactive antibodies have been reported at low levels in healthy donor cohorts<sup>1</sup>, inconclusive data may reflect this phenomenon and can be verified with clinical information. Concentrations reported between the minimum detectable concentration and C2 (0.488 ng/mL) were considered inconclusive and excluded from calculating % of detectable. Users may modify this cutoff. The concentrations after multiplying by the dilution factor are shown below (in ng/mL).

Analyte	Range (ng/mL)	% Detectable	Median (ng/mL)
Anti-Spike S1 IgG	ND-992	8%	8.6
Anti-Nucleocapsid IgG	ND-2224	10%	80
Anti-S Protein RBD IgG	ND-328	0%	0

<sup>1</sup>K.W. Ng *et al.*, *Science* 10.1126/science.abe1107 (2020)

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Bead population shifting upward or downward during acquisition	The strong PE signal from high concentration samples or standards may spill over to classification Channel (e.g., FL3/FL4/APC) and mess up the bead separation.	Optimize instrument settings using Kit Setup Beads, and make appropriate compensation between channels.
Filter plate will not vacuum or some wells clogged	Vacuum pressure is insufficient or vacuum manifold does not seal properly.	Increase vacuum pressure such that 0.2 mL buffer can be suctioned in 3-5 seconds. Clean the vacuum manifold and make sure no debris on the manifold. Press down the plate on the manifold to make a good seal.
	Samples have insoluble particles or sample is too viscous (e.g., serum and plasma samples)	<p>Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.</p> <p>If some wells are still clogged during washing, try the following:</p> <ol style="list-style-type: none"> <li>1). Add buffer to all the wells, pipette up and down the clogged wells and vacuum again.</li> <li>2). Use a piece of clean wipe, wipe the under side of the clogged wells and vacuum again.</li> <li>3). Take a thin needle (e.g., insulin needle), while holding the plate upward, poke the little hole under each of the clogged wells and vacuum again. Do not poke too hard or too deep as it may damage the filter and cause leaking.</li> </ol>
	Filter plate was used without pre-wet.	Pre-wet plate with wash buffer before running the assay.

# LEGENDplex™ SARS-CoV-2 Serological IgG Panel

Insufficient bead count or slow reading	Beads inappropriately prepared	Sonicate bead vials and vortex just prior to addition. Agitate mixed beads intermittently in reservoir while pipetting this into the plate.
	Samples cause beads aggregation due to particulate matter or viscosity.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
	Beads were lost during washing for in-tube assay	Make sure beads are spun down by visually check the pellet (beads are in light blue or blue color). Be very careful when removing supernatant during washing.
	Probe might be partially clogged.	Sample probe may need to be cleaned, or if needed, probe should be removed and sonicated.
Plate leaked	Vacuum pressure set too high	Adjust vacuum pressure such that 0.2 mL buffer can be suctioned in 3-5 seconds. Do not exceed 10" Hg of vacuum.
	Plate set directly on table or absorbent towels during incubations or reagent additions	Set plate on plate holder or raised edge so bottom of filter is not touching any surface.
	Liquid present on the under side of the plate after vacuum	After washing, press down plate firmly on a stack of clean paper towels to dry the underside of the plate.
	Pipette touching and damaged plate filter during additions.	Pipette to the side of wells.
High Background	Background wells were contaminated	Avoid cross-well contamination by changing tips between pipetting when performing the assay using a multichannel pipette.
	Insufficient washes	The background may be due to non-specific binding of SA-PE. Increase number of washes.
Debris (FSC/SSC) during sample acquisition	Debris or platelet may exist in sample solution.	Centrifuge samples before analyzing samples. Remove platelet as much as possible.

## LEGENDplex™ SARS-CoV-2 Serological IgG Panel

Variation between duplicate samples	Beads aggregation	Sonicate and vortex the Beads prior to use.
	Multichannel pipette may not be calibrated or inconsistent pipetting	Calibrate Pipette. Ensure good pipetting practice. Prime pipette before use may help.
	Plate washing was not uniform	Make sure all reagents are vacuumed out completely in all wash steps.
	Samples may contain particulate matters.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
Low or poor standard curve signal	The standard was incorrectly reconstituted, stored or diluted	Follow the protocol to reconstitute, store and dilute standard. Double check your calculation.
	Wrong or short incubation time	Ensure the time of all incubations was appropriate.
Signals too high, standard curves saturated	PMT value for FL2/PE set too high	Make sure the PMT setting for the reporter channel is appropriate
	Plate incubation time was too long	Use shorter incubation time.
Sample readings are out of range	Samples contain no or below detectable levels of analyte	Make sure the experiment to generate the samples worked. Use proper positive controls.
	Samples concentrations higher than highest standard point.	Dilute samples and analyze again.
	Standard curve was saturated at higher end of curve.	Make sure the PMT setting for the reporter channel is appropriate. Use shorter incubation time if incubation time was too long
Missed beads populations during reading, or distribution is unequal	Sample may cause some beads to aggregate.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
	Beads populations are not mixed properly	Make sure all bead populations are mixed. and in similar numbers.







**PLATE MAP (for in-plate assay)**

	1	2	3	4	5	6	7	8	9	10	11	12
A	C0	C4	Sample1	Sample5	Sample 9	Sample 13	Sample 17	Sample 21	Sample 25	Sample 29	Sample 33	Sample 37
B	C0	C4	Sample1	Sample5	Sample 9	Sample 13	Sample 17	Sample 21	Sample 25	Sample 29	Sample 33	Sample 37
C	C1	C5	Sample2	Sample6	Sample 10	Sample 14	Sample 18	Sample 22	Sample 26	Sample 30	Sample 34	Sample 38
D	C1	C5	Sample2	Sample6	Sample 10	Sample 14	Sample 18	Sample 22	Sample 26	Sample 30	Sample 34	Sample 38
E	C2	C6	Sample3	Sample7	Sample 11	Sample 15	Sample 19	Sample 23	Sample 27	Sample 31	Sample 35	Sample 39
F	C2	C6	Sample3	Sample7	Sample 11	Sample 15	Sample 19	Sample 23	Sample 27	Sample 31	Sample 35	Sample 39
G	C3	C7	Sample4	Sample8	Sample 12	Sample 16	Sample 20	Sample 24	Sample 28	Sample 32	Sample 36	Sample 40
H	C3	C7	Sample4	Sample8	Sample 12	Sample 16	Sample 20	Sample 24	Sample 28	Sample 32	Sample 36	Sample 40



LEGENDplex™ Kits are manufactured by **BioLegend**  
8999 BioLegend Way  
San Diego, CA 92121  
Tel: 1.858.768.5800  
Tel: US & Canada Toll-Free: 1.877.Bio-Legend (1.877.246.5343)  
Fax: 1.877.455.9587  
Email: [info@biolegend.com](mailto:info@biolegend.com)  
[biolegend.com](http://biolegend.com)

For a complete list of world-wide BioLegend offices and distributors,  
please visit our website at: [biolegend.com](http://biolegend.com)